

Roscore Daemon

Some may find it convenient to have roscore automatically launched as a system service on startup. To do this:

```
roslaunch robot_upstart install --job roscore robosub/launch/roscore.launch
```

Once installed, you can use the normal service tools to manage the service:

```
sudo service roscore status
sudo service roscore start
sudo service roscore restart
sudo service roscore stop
```

To uninstall the service:

```
roslaunch robot_upstart uninstall roscore
```

References: http://docs.ros.org/jade/api/robot_upstart/html/

From:

<http://robosub-old.eecs.wsu.edu/wiki/> - **Palouse RoboSub Technical Documentation**

Permanent link:

http://robosub-old.eecs.wsu.edu/wiki/cs/roscore_daemon/start



Last update: **2016/10/09 13:13**