

Battery Charging

Charging Menu Controls



'-'

- Cycles through the charging options for the battery chemistry

'+'

- Should cycle in the opposite direction of '−', but there is a short between it and 'PORT' on this charger.

'PORT'

- Switch between ports, it will also change battery chemistry

'MODE'

- Cycles between the Charging menu, Data View, and Settings Data.
- Inside these options, use '−' to cycle through all the options.

'ENTER'

- A long press (~1 second) starts the charging cycle.
- A short press cycles through the options on the screen, it lets you change the capacity it lets

From:

<http://robosub-old.eecs.wsu.edu/wiki/> - Palouse RoboSub Technical Documentation

Permanent link:

<http://robosub-old.eecs.wsu.edu/wiki/ee/battery/start?rev=1518652881>

Last update: **2018/02/14 16:01**

