

# USB Setup

To cause USB devices to show up as a special name (i.e. `/dev/sensor_microcontroller` instead of `/dev/ttyUSB0`), we need to modify our UDEV rules.

First, open up

```
/etc/udev/rules.d/50-usb.rules
```

Then add a line for the USB device, such as

```
SUBSYSTEM=="tty", ATTRS{idVendor}=="2a03", ATTRS{idProduct}=="0043",  
SYMLINK+="sensor_arduino"
```

To properly identify the vendor and product id, you will want to run `lsusb`, and take a look at the ID field for the proper device.

From:

<http://robosub-old.eecs.wsu.edu/wiki/> - **Palouse RoboSub Technical Documentation**

Permanent link:

<http://robosub-old.eecs.wsu.edu/wiki/cs/udev/start?rev=1475784411>



Last update: **2016/10/06 13:06**